



D-8 Instructions

TO BEGIN:

- **CONNECT INSTRUMENT CABLE TO THE INPUT JACK. CONNECT AMPLIFIER CABLE TO THE OUTPUT JACK. IF USING AN AC ADAPTER, CONNECT TO 9V DC JACK. OR USE 9-VOLT BATTERY.**
- **LED LIGHT WILL BE ON WHEN FOOT SWITCH IS ACTIVATED.**


CONTROL FUNCTIONS:

REPEAT: SETS THE DELAY REPEATS WHEN THE PEDAL IS ON. AT MINIMUM (FULLY COUNTER-CLOCKWISE) THERE WILL BE ONE REPEAT OF A PLAYED NOTE. AT MAXIMUM (FULLY CLOCKWISE) THERE WILL BE MULTIPLE REPEATS THAT SLOWLY FADE.

TIME: SETS THE DELAY TIME FROM 80MS TO 600MS.

DELAY: SETS THE LEVEL OF THE DELAYED SIGNAL WHEN THE PEDAL IS ON. FULLY CLOCKWISE GIVES THE MAXIMUM AMOUNT OF DELAYED SIGNAL. AT FULLY COUNTER-CLOCKWISE, THERE IS NO DELAY SIGNAL EVEN WHEN THE PEDAL IS ON.

REPEAT: SETS THE AMOUNT OF DELAY REPEATS
TIME: ADJUSTS THE DELAY TIME
DELAY: ADJUSTS THE DELAY SIGNAL



BATTERY: USES ONE S-006P 9-VOLT BATTERY. DANELECTRO "VINTAGE POWER SOURCE" BATTERIES ARE RECOMMENDED.

BATTERY ELIMINATOR: USES 9-VOLT BATTERY ELIMINATOR.
POLARITY: CENTER NEGATIVE (-). 300MA MAXIMUM. DANELECTRO "ZERO HUM" BATTERY ELIMINATORS ARE RECOMMENDED.

This product complies with FCC Part 15 rules. Operation of this product is permitted in USA provided this product does not cause harmful interference and provided this product accepts interference from other devices, even if that interference is detrimental to performance of this product.

EEC Agent:
John Hornby Skewes & Co., Ltd.
Salem House, Parkinson Approach,
Garforth, Leeds LS25 2HR UK



© EC 2010 Printed in China



INSTRUCTIONS